


12,000 LB. 2-POST AUTOMOBILE LIFT



▲ IMPORTANT Reference ANSI/ALI ALIS,
Safety Requirements for
Installation and Service of Automotive Lifts
before installing lift.

Table of Contents

Chapter/Paragraph	Page
Important Safety Instructions	3
Safety Summary	4
General Safety Instructions	4
Warnings, Cautions, and Notes.....	4
1 General Information and Specifications.....	4
General Information.....	4
Specifications	5
2 Installation and Preparation for Use	6
General Information.....	6
Tools and Equipment Required	6
Foundation Requirements	6
Installation	7
Assemble Columns and Uprights	8
Installation of Overhead Beam	11
Installation of Power Unit.....	12
Installation of Equalizing Cables	12
Installation of Overhead Switch.....	16
Installation test.....	19
3 Operating Instructions.....	20
Safety Procedures	20
Daily Pre-Operation Check (8-Hours).....	20
Controls	21
Operation.....	22
Positioning Vehicle	22
Raising Vehicle.....	23
Lowering Vehicle	23
4 Maintenance and Troubleshooting	25
Maintenance	25
Owner/Employer Responsibilities.....	25
Periodic Maintenance Schedule.....	25
Daily Pre-Operation Check (8-Hours)	25
Weekly Maintenance (every 40-Hours).....	25
Yearly Maintenance	26
Special Maintenance Tasks	26
Troubleshooting.....	26
Motor Does Not Operate	26
Motor Functions but Lift Will Not Rise	26
Oil Blows out Breather of Power Unit	26
Motor Hums and Will Not Run.....	26
Lift Jerks Going Up and Down.....	28
Oil Leaks	28
Lift Makes Excessive Noise.....	28
5 Safety Instructions.....	29
6 Lift Lockout / Tagout Procedure.....	31
7 Illustrated Parts Breakdown.....	32

IMPORTANT SAFETY INSTRUCTIONS

When using your garage equipment, basic safety precautions should always be followed, including the following:

1. Read all instructions
2. Care must be taken as burns can occur from touching hot parts.
3. Do not operate equipment with a damaged cord or if the equipment has been dropped or damaged – until it has been examined by a qualified service person.
4. Do not let a cord hang over the edge of the table, bench, or counter or come in contact with hot manifolds or moving fan blades.
5. If an extension cord is necessary, a cord with a current rating equal to or more than that of the equipment should be used. Cords rated for less current than the equipment may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
6. Always unplug equipment from electrical outlet when not in use. Never use the cord to pull the plug from the outlet. Grasp plug and pull to disconnect.
7. Let equipment cool completely before putting away. Loop cord loosely around equipment when storing.
8. To reduce the risk of fire, do not operate equipment in the vicinity of open containers of flammable liquids (gasoline).
9. Adequate ventilation should be provided when working on operating internal combustion engines.
10. Keep hair, loose clothing, fingers, and all parts of body away from moving parts.
11. To reduce the risk of electric shock, do not use on wet surfaces or expose to rain.
12. Use only as described in this manual. Use only manufacturer's recommended attachments.
13. **ALWAYS WEAR SAFETY GLASSES.** Everyday eyeglasses only have impact resistant lenses, they are not safety glasses.

SAVE THESE INSTRUCTIONS

Safety Summary

General Safety Instructions

This summary describes physical and chemical processes that may cause injury or death to personnel, or damage to equipment if not properly followed. This safety summary includes general safety precautions and instructions that must be understood and applied during operation and maintenance to ensure personnel safety and protection of equipment. Prior to performing any task, the WARNINGS, CAUTIONs, and NOTEs included in that task should be reviewed and understood.

Warnings, Cautions, and Notes

WARNINGS and CAUTIONs are used in this manual to highlight operating or maintenance procedures, practices, conditions or statements that are considered essential to protection of personnel (WARNING) or equipment (CAUTION). WARNINGS or CAUTIONs immediately precede the step or procedure to which they apply. NOTEs are used in this manual to highlight operating or maintenance procedures, practices, conditions or statements that are not essential to the safeguarding of personnel or equipment. NOTEs may precede or follow the step or procedure, depending on the information to be highlighted. The Headings used and their definitions are as follows.

WARNING!

Highlights essential operating or maintenance procedure, practice, condition, statement, etc. that if not strictly observed, could result in injury to, or death of, personnel or long term health hazards.

CAUTION!

Highlights essential operating or maintenance procedure, practice, condition, statement, etc. that if not strictly observed, could result in damage to, or destruction of equipment.

NOTE

Highlights essential operating or maintenance procedure, practice, condition, or statement.

1 General Information and Specifications

General Information


This lift is a 12,000 lb. capacity, two-column lift. The safety system in this lift is attached to the back of the carriage to provide a single point release that saves time when operating. This lift is equipped with two heavy-duty direct-drive cylinders to provide consistent power to the lift.

An electrical-hydraulic power unit included with the lift will provide up to 3000 psi of hydraulic pressure to actuate the cylinders.

Specifications

The specifications are shown in the following table.

Basic Specifications



Specification	Value
A. Rise Height	82-1/2 in., Highest position, with long truck adapter
B. Adjustable Overall Height	165 in. Standard Setup; 177 in. High Setup
C. Width Overall	150-3/8 in.
D. Drive Through	109-1/2 in.
E. Floor to Overhead Switch	159-3/8 in. Low, 171-3/8 in. High
F. Front Arm Reach	Min. 38-1/2 in./Max. 57-1/2 in.
G. Real Arm Reach	Min. 38-1/2 in./Max. 57-1/2 in.
H. Lifting Pad Height	6 in.
Lifting Pad Height w/Short Ext.	10-1/2 in.
Lifting Pad Height w/High Ext.	14-1/2 in.
I. Between Columns	123-1/4 in.
Lifting Capacity	12000 Lbs
Max. Load Per Arm	3000 Lbs per arm
Cylinders	Dual Cylinder, Direct Drive
Motor	2 HP
Voltage	208v - 230v
Speed of Rise	60 Seconds

2 Installation and Preparation for Use

General Information

- 1 Any freight damage must be noted on the freight bill before signing and reported to the freight carrier with a freight claim established. Identify the components and check for shortages. If shortages are discovered, contact lift manufacturer immediately.
- 2 Consult building owner and / or architect's plans when applicable to establish the best lift location. The lift should be located on a relatively level floor with 4 in. minimum thickness, 3000-psi concrete slab that has been properly cured. There can be no cracks in the slab within 36 in. of the base plate locations, and no seams in the foundation within 6 in. of its' location! Remember: any structure is only as strong as the foundation on which it is located!
- 3 This lift has two set-up dimensions as below:
 - a) STANDARD set-up
 - 1) Overhead Clearance: 165 in.
 - 2) Ceiling Height Required: 167 in.
 - b) HIGH set-up
 - 1) Overhead Clearance: 177 in.
 - 2) Ceiling Height Required: 179 in.

NOTE

Check for ceiling clearance first to see how high the lift can be set up in your bay.

Tools and Equipment Required

The installation of this lift is relatively simple and can be accomplished by two men in a few hours. The following tools and equipment are needed:

- Appropriate lifting equipment
- AW 32, 46 or other good grade Non-Detergent Hydraulic Fluid DEXRON III or ATF (10 quarts)
- Chalkline and 12' Tape Measure
- Rotary Hammer Drill with 3/4 in. Drill Bit. Core Drill Rebar Cutter recommended
- Transit and a 4' Level
- Sockets and Open Wrench set, 1/2 in. thru 1-1/2 in. (1-1/8 in. for 3/4 in. Anchors)
- Locking Pliers, 8mm Socket Head Wrench

Foundation Requirements

CAUTION!

Columns are supported only by anchoring in the floor. DO NOT install on asphalt or other similar unstable surface failure to follow the requirements of the following step could result in damage to, or destruction of equipment.


Assemble Columns and Uprights

Concrete And Anchoring Requirements
Floor Requirements: Minimum 3000 PSI concrete
Optimum Floor Thickness: 5-1/2" -6"
Minimum Floor Thickness: 4-1/4"
Minimum Anchor Embedment: 3-1/4"
Maximum Anchor Exposure Floor Grade to Top of Anchor: 2-1/4". Exposure greater than 2-1/4" NOT ACCEPTABLE.
Note: Anchors are provided for standard installation the minimum distance you can install them to an edge, expansion joint, or abandoned anchor hole is 2-3/4".
For installations not meeting these requirements or for seismic anchor information contact customer service.

Assemble the columns and uprights according to the following steps:

- 1 After unloading the lift, place it near the intended installation location.
- 2 Remove the shipping bands and packing materials from the lift. The power unit will be unpacked from the top. Take out all parts and components packed inside the column other than carriage, including cylinders.
- 3 Unbolt the column from the shipping brackets. Unbolt the up-rights from the columns and assemble it to the column as shown in figure 2-2.

Figure 2-2. Overhead Beam and Upright Assembly



Installation and Preparation for Use

4. Open the oil port on each cylinder by unscrewing the black plastic cap. The oil port is located in the cylinder rod end that will fit into the hole on the bottom plate of the column. Move the carriage up about 50 in. to 60 in. Next, carefully slide the cylinder inside from the bottom of the carriage.

WARNING!

Failure to position the columns as directed in the following step could result in foundation damage that can cause death or serious injury as well as damage to the equipment. Columns are supported only by anchoring in the floor. DO NOT install on asphalt or other similar unstable surfaces.

5. Position the columns facing each other 150-3/8 in. outside base plates (see figure 2-3). Allow a minimum of 6 in. from the column base plate to the foundation edge. Square the columns by using a chalkline or measuring diagonally from corner points on base plates (within 1/4 in.). Trace around the column base plates to make sure that positions do not shift in the following steps.




Figure 2-3. Placement of Columns on Foundation

WARNING!

Failure to follow the requirements of the following step could result in damage to, or destruction of equipment. If anchors do not tighten to 150 ft-lbs. installation torque, replace the concrete under each column base with a 4' x 4' x 6 in. thick 3,000 PSI minimum concrete pad keyed under and flush with the top of existing floor. Allow concrete to cure and return to Step 5.

Installation and Preparation for Use

6. Secure the columns to the foundation as follows (refer to figure 2-4):
- a) Using a 3/4 in. diameter concrete drill, drill the anchor holes in the concrete for the main side column, installing anchors as you go. Use a concrete hammer drill with a carbide tip solid drill bit the same diameter as the anchor, 3/4". (.775 to .787 inches diameter). Do not use excessively worn bits or bits which have been incorrectly sharpened. Refer to figure 2-4 Detail A. Use the following guide while drilling the anchor holes in the concrete:
 - 1) Keep the drill in a perpendicular line while drilling.
 - 2) Drill to a minimum depth of 4 in. to make sure maximum holding power is achieved. Drilling thru concrete (recommended) will allow the anchor to be driven thru the bottom if the threads are damaged.
 - 3) Let the drill do the work. Do not apply excessive pressure. Lift the drill up and down occasionally to remove residue to reduce binding.
 - 4) For better holding power blow dust from the hole (Refer to figure 2-4 Detail B).
 - 5) If anchors do not tighten to 150 ft-lbs. installation torque, replace concrete under each column base with a 4' x 4' x 6" thick 3000 PSI minimum concrete pad keyed under and flush with the top of existing floor. Let concrete cure before installing lifts and anchors.




Figure 2-4. Anchor Hole Drilling and Seating

- b) Place a flat washer and hex nut over threaded end of anchor, leaving approximately 1/2 inch of thread exposed and carefully tap anchor (Refer to figure 2-4 Detail C). Do not damage threads. Use a block of wood or rubber mallet to drive anchor bolts into the concrete.
- c) Tap anchor into the concrete until nut and flat washer are against base plate. Do not use an impact wrench to tighten (Refer to figure 2-4 Detail D).
- d) Tighten the nut (two or three turns on average concrete (28-day cure). If the concrete is very hard, only one or two turns may be required. Check each anchor bolt with torque wrench set to 150 foot-pounds.

Installation and Preparation for Use

NOTE

If 150 foot-pounds of torque cannot be obtained on any anchor, return to the warning preceding step 6 and follow the instructions in the warning.

7. Using a level, check column for side-to-side plumb and front-to-back plumb. If needed, use horseshoe shims provided by placing shims underneath the base plate and around the anchor bolt. This will prevent bending the column bottom plates (Shim thickness should not exceed ½ in.). Tighten ¾ in. anchor bolts to 85 ft-lbs. of torque.

NOTE

If 85 foot-pounds of torque cannot be obtained on any anchor, return to the warning preceding step 6 and follow the instructions in the warning.

8. Using a tape measure and chalk line, measure from back of the base to the opposite column to make sure the legs are square. After confirming dimensions, drill and install the anchors on the other side leg as given in step 6.

9. Level the second column as described in step 7.

2.4.2 Installation of Overhead Beam

Install the overhead beam as follows:

1. Install the overhead cross beam as shown in figure 2-5. This cross beam has two pieces, to be connected by six (6) bolts in the center of the beam. **Be sure to bolt them together by installing the bolts from inside the cross beam out.** This is to avoid interference with the cable when operating the lift.
2. Bolt overhead beam assembly to column up-rights. Overhead beam has hooks on each end to aid assembly.




Figure 2-5. Overhead Beam Installation

3. Mount the latch cable brackets to the tops of the column extensions and onto the offside column.
4. Run the straight end of the latch release cable (the end without the loop) through the hole in the offside latch, down under the cable guide, over the bracket at the top of the offside column, over and down the bracket on the mainside column, and through the latch on the mainside lock release. Tighten the cable adjusting nut after pulling slack out of the cable.

Installation of Power Unit

Install the power unit as follows. Refer to figure 2-7:

- 1 Mount the power unit on the main side leg to the power unit bracket using the four 8mm bolts and nuts. Install the "T" fitting with o-ring on the power unit, and then install the adapter and flow control valve, into the backside of each cylinder. (Note direction of flow on valve. Arrow on valve points away from the cylinder.)
- 2 Connect the 90-degree hydraulic fitting on the other end of the flow control valve.
- 3 Connect the short hydraulic hose to one side of the "T" fitting at power unit, then run the hose down the column and connect to the elbow on the base of cylinder.
- 4 Connect the long hydraulic hose to the other side of the "T" fitting. Place the hose across over the overhead beam to the opposite column, then down the side and connect to the elbow on the other column cylinder. Make sure hose goes through hose guides / retainers in center of overhead beam.

Installation of Equalizing Cables

Connect the equalizing cables as shown in figure 2-8 by doing the following in the order given:

NOTE

For lower setting use cable attachment points further up inside of carriages.

NOTE

The cables can be installed in the lower bracket on carriage before standing up column to ease assembly.

NOTE

Do not tighten at this stage of assembly.

- 1 Note – The cable stud that connects to the front right corner of the carriage should be connected first by pulling the stud through the carriage hole and up where it is easy to be held by locking pliers. Pull the stud back into place after threading at least ½ in. of the stud past locknut.
- 2 Connect the other ends to the right corners of the carriage with at least ½ in. of thread showing past lock nut (cables run on inside of carriage). It may be necessary to manually raise both carriages above the cylinder to provide enough space to use the locking pliers. Make sure the carriage is set in the LOCK position.
- 3 Adjust the carriage cable tension. This is accomplished by tightening the center nut on top of each carriage. The center carriage adjustment nut adjusts the opposite post carriage height. The left post carriage nut adjusts the right column carriage, and the right column carriage nut adjusts the left column carriage. Adjust each cable to approximately 1/2 in. side-to-side play. Check the latch releases to make sure the carriage is still engaged in the appropriate latch.

Installation and Preparation for Use

- 4 Install the half moon gear locks on each swing arm (USA side up). Position the swing arms on the carriages using the included 1 1/2 in. diameter pins. Check for proper engagement of the arm lock – the rack on the lock should fully engage the gear on the arm.




Figure 2-6. Safety Release Cable Installation




Figure 2-7. Power Unit Installation




Figure 2-8. Installation of Equalizing Cables

5. Install Overhead Switch

Slide Switch Box over switch bar ensuring knock out holes face the power unit column. Use (2) 1/4"-20NC x 3/4" lg. HHCS, 1/4"-20NC Nuts and 1/4" Star Washers to mount switch box to overhead.

5a. Continued Overhead Assembly:

For single phase lifts (Figure 2-9): Insert 1/4"-20NC x 2-3/4" HHCS through pivot hole in end of switch bar. Insert opposite end of bar through slot in switch mounting bracket. Then secure HHCS and Switch Bar to overhead as shown, Fig. 11, using (2) 3/4" spacers and 1/4"-20NC Locknut. Tighten Hex bolt leaving 1/16" gap between the spacer and the overhead assembly.





Figure 2-9
Overhead Switch
Single Phase

For three phase lifts (Figure 2-9a): Remove Limit Switch cover, Fig. 2-9a. Insert Actuator end of Switch Bar into slot located inside Limit Switch. A small amount of silicone sealant on the lower part of the actuator will help hold it in place. Insert 1/4"-20NC x 2-3/4" HHCS through pivot hole in end of Switch Bar. NOTE which hole to use. Then secure HHCS and Switch Bar to overhead as shown, using (2) 3/4" spacers and 1/4"-20NC Locknut. Tighten Hex bolt leaving 1/16" gap between the spacer and the overhead assembly. Replace limit switch cover.



Place Actuator Here.
A Small Amount Of Silicone Sealant
On The Lower Part Of The Actuator
Will Help Hold It In Place.





Figure 2-9 a
Overhead Switch
Three Phase

Installation and Preparation for Use

6. Wire overhead switch per figure 2-10.

WARNING!

Failure to comply with this warning could result in death or injury. The wiring must comply with local code. In the following step have a certified electrician make the electrical hook-up to the power unit. Protect each circuit with time delay fuse or circuit breaker rated at 208v-230v single phase. 60 Hz 20 amp. Motor cannot run on 50 Hz without a physical change to motor



7. Make the Electrical hookup to the power unit; 220V Single Phase. It is recommended that a 220 Volt, 30 Amp twist lock plug be installed in the power line just ahead of the power unit. Use wire capable of supporting a 20-amp circuit.

CAUTION!

Failure to comply with this caution could result in damage to the lift. Do not place any vehicle on the lift at this time.

Single Phase Power Unit

MOTOR OPERATING DATA TABLE - SINGLE PHASE	
LINE VOLTAGE	RUNNING MOTOR VOLTAGE RANGE
208-230V 50Hz.	197-253V
208-230V 60Hz.	197-253V







Note: 60Hz. Single phase motor CAN NOT be run on 50Hz. line without a physical change in the motor.

Figure 2-10 Wiring Overhead Switch

NOTE: Two Different Drum Switches were used please select one of the two options below.


NOTES:

1. Unit not suitable for use in unusual conditions. Contact Rotary for moisture and dust environment duty unit.
2. Control Box must be field mounted to power unit.
3. Motor rotation is counter clockwise from top of motor.




Three Phase Power Unit


MOTOR OPERATING DATA TABLE - THREE PHASE	
LINE VOLTAGE	RUNNING MOTOR VOLTAGE RANGE
208-240V 50/60Hz.	197-253V
400V 50Hz.	360-440V
440-480V 50/60Hz.	396V-528V
575V 60Hz.	518V-632V



208-240V
50/60Hz. 3Ø



440-480V 50/60 Hz. 3Ø
380-400V 50 Hz. 3Ø



575V 60 Hz. 3Ø

8. **Oil Filling & Bleeding:** Use a Ten Weight (SAE-10) non-foaming, non-detergent hydraulic fluid (Texaco HD46 or Dexron III ATF), or Hydraulic Fluid that meets ISO 32 specifications. Remove fill-breather cap, Fig. 3-1. Pour in (8) quarts of fluid. Start unit, raise lift about 2 ft. Open cylinder bleeders approximately 2 turns.

Close bleeders when fluid streams. Torque values for the bleeders are 15 ft. lb. minimum and 20 ft lb. maximum. Fully lower lift. Add more fluid until it reaches the MIN _____ mark on the tank. Replace fill-breather cap.

CAUTION!

If fill-breather cap is lost or broken, order replacement. Reservoir must be vented.

9. Cycle the lift up and down several times to make sure latches engage properly and all air is removed from the system. To lower the lift, first raised the lift to clear the latches and then pull down the safety release handle to lower the lift. If latches function out of synchronization, tighten the cable on the latch that engages first.

Installation test

Test the Lift operation by doing the following:

10. Raise the lift by pressing the button on the power unit.

NOTE

The safety latch mechanism will 'trip over' when the lift raises and drop into each latch stop. To lock the lift you must press the Lower lever to relieve the hydraulic pressure and let the latch set tight in a lock position.

NOTE

In the following step it is normal for an empty lift to lower slowly - it may be necessary to add weight.

11. Lower the lift by doing the following:

a) Raise the lift until the latches clear the safety racks in both sides.

CAUTION!

Failure to comply with this caution could result in damage to the lift. In the following step always make sure latches on both sides clear the rack at same time when pulling down the release handle by adjusting the cable

b) Pull down and hold the safety release handle.

c) Press the lowering lever at the power unit to lower the lift.

Vehicle Service GroupSM
2700 Lanier Drive
Madison, IN 47250, USA
1-800-640-5438
www.vsgdover.com



© **Vehicle Service GroupSM**
All Rights Reserved. Unless otherwise
indicated, **Vehicle Service GroupSM**
and all other trademarks are property
of Dover Corporation and its affiliates.